


## Button SPEC

- 1.Double Injection Right Button
- 2.Double Injection Scrolling Wheel
- 3.Double Injection Left Button
- 4.Forward Button
- 5.Backward Button
- 6.Power Button (Push Push Type)
- 7.Silicon Pairing Button
- 8.Battery Cover
- 9.Optical Sensor
- 10.Mini USB Power Supply Connect
- 11.3 Color LED (Pairing LED-Blue, Rechargeable LED-Rad&Green)



## LED light indicator

- Red LED light — recharging
- Green LED light — recharging completely
- Flashing Green LED light — unable recharging
- Flashing Red LED light — No battery inside
- Flash Red & Green light — Power supply detection
- Blue LED light — Pairing researching
- Blue LED light off — Pairing successfully



## Install Batteries

- A.Remove the battery Cover
- B.Refer to the battery +/- mark shown in the slot
- C.Put 2pcs AA batteries into the slot

## Caution:

- Pairing code : 0000
- Please re-press the power button when pairing

is not successful.

If BT mouse still fail for pairing, please remove the HID mouse in BT software and then re-install again.

- Please refer to the user guide for different bluetooth applied software.
- Please do not recharge with non-rechargeable battery to avoid dangerous.
- Please remove the USB cable and power off when seeing flashing RED and GREEN LED light first and then connect with USB cable again.  
If the LED light keep flashing again,please check the battery pack.
- Please recharge through the PC or Notebook USB directly.  
To charge through USB HUB is prohibited.

